


1. Package Contents

- 1. ET-AR506-BK
- 2. User Manual
- 3. 3.5 mm to RCA audio cable




2. Safety Instructions


Warning: Electric Shock Hazard

- 1. Do not use this product near water.
- 2. Unplug from AC outlet when not in use and before cleaning.
- 3. Close supervision is necessary when used near children.
- 4. Clean only with dry cloth.
- 5. Do not attempt to repair the product on your own. It contains no user serviceable parts.

3. Product Overview




- 1. **Power Switch**
Turns Power On / Off
- 2. **Volume Control**
Turns Volume Up / Down
- 3. **Power LED**
Power on indicator
- 4. **Mute Button**
Press to mute



- 5. **Headphone**
Connects to headphones
- 6. **Power Cord**
Connects to 120V AC Outlet
- 7. **Audio Input**
Connects to your music device
- 8. **Audio Output**
Connects to left and right satellite speakers

4. Product Setup

- 1. Connect your music device to audio input.
- 2. Connect left and right satellites to audio output.
- 3. Connect the power cord to 120V AC outlet.
- 4. Release the mute button. Slowly increase volume until reaching a comfortable level.
- 5. You can connect headphone to speaker's headphone jack. No sound will be output from the speakers while the headphone is connected.



5. Frequently Asked Questions

Speaker turns off: Disconnect AC power and wait 1 minute before reconnecting. Incorrectly wired speakers may overload the amplifier and cause a temporary shutdown. Check audio wire polarity.

No sound is heard from the speakers: Try the speaker mute button. Check the audio settings on your computer or smartphone. Unplug headphone connected to the headphone output jack.

One of the two satellites is not working: Check audio wires are not bent. Switch left and right speakers to see if problem persists.

Sound is distorted: Lower the speaker volume and/or bass level. Check the audio settings on your computer or smartphone. Try moving the subwoofer closer or farther away from a wall or corner to affect the bass performance.

6. Specifications

Power Source: 120 VAC 60 Hz
Total Peak Power: 100 Watts
Total RMS Power: 50 Watts
Satellite RMS Power: 12.5 Watts x 2
Subwoofer RMS Power: 25 Watts x 1
Frequency Response: 20 Hz to 20 kHz
Satellite Drivers: dual 3 inch woofers and 1 inch tweeter in wooden cabinet
Subwoofer Drivers: dual 5 inch subwoofer in wooden cabinet
Satellite Dimensions: 3.94 x 10.52 x 4.93 inches
Subwoofer Dimensions: 6.58 x 12.05 x 9.49 inches

7. Regulatory Compliance

FCC Class B Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

CE Compliance for Europe

This equipment has been tested and found to comply with the limits for European Council Directive on the approximation of the law of the member states relating to electromagnetic compatibility (89/336/EEC) according to EN55022 Class B.

8. Limited Warranty

Arion Legacy warrants that the product, in the course of its normal use, will be free from defects in material and workmanship for a period of one (1) year. This limited warranty period shall commence on the purchase date appearing on your purchase receipt. Arion Legacy shall have no liability for any product returned if Arion Legacy determines that the product was not purchased from authorized retailers, that the asserted defect a) is not present, b) cannot reasonably be rectified because of damage occurring before Arion Legacy receives the Product, or c) is attributable to misuse, improper installation, alteration (including removing or obliterating labels and opening or removing parts). The foregoing warranty shall extend to repaired or replaced products for the remaining of the applicable period of the original warranty or ninety (90) days from the date of shipment of a repaired or replaced product, whichever is longer.

9. Contact Us

Website	www.arionlegacy.com
FAQ	support.arionlegacy.com
Customer Support	1-951-373-3790 (US) customerservice@arionlegacy.com
General Information	1-844-EAGLETECH (US) 1-626-956-4040 (International)




@ArionLegacy

© 2014 Arion Legacy. All rights reserved. Arion Legacy, the Arion Legacy logo and other Arion Legacy marks are owned by Eagle Tech Computers Inc and may be registered. All other marks are property of their respective owners.

1. Contenido del paquete

1. ET-AR506-BK
2. Manual del usuario
3. Cable de audio RCA a 3.5 mm




2. Instrucciones de seguridad


Precaución: Peligro de descarga eléctrica.

1. No utilice este producto cerca del agua.
2. Desconecte el aparato de toma de corriente cuando no esté en uso y antes de limpiarlo.
3. Se requiere supervisión de adultos cuando utiliza cerca de niños.
4. Limpie sólo con un paño seco.
5. No intente reparar o abrir el producto.

3. Descripción del producto




1. **El interruptor**
Encender or apagar las bocinas
2. **Control de volumen**
Aumenta o disminuye el volumen
3. **LED**
Indica si el sistema esta encendido o apagado
4. **Mudo**
Silenciar el sistema



5. **Audífono**
Conecta a un audífono
6. **Cable de poder**
Conecta a un enchufe 120Vca
7. **Entrada de audio**
Conecta a su dispositivo de música
8. **Salida de audio**
Conecta a los satélites izquierdo y derecho

4. Configuración de producto

1. Conecta su dispositivos de música a entrada de audio.
2. Conecta los satélites izquierdo y derecho a salida de audio.
3. Conecta el cable de poder a un enchufe 120Vca.
4. Suelte el botón de mudo. Sube el volumen lentamente hasta llegar a un nivel cómodo.
5. Puedes conectar un audífono a este sistema de bocinas. No hay sonido a través de los altavoces mientras el audífono está conectado.



5. Preguntas frecuentes

La bocina se apaga: Desconecte el sistema de la toma de corriente y espere 1 minuto antes de volver a conectar. Conexiones incorrectas pueden sobrecargar el amplificador y causar un apagado temporal. Revise la polaridad de los cables de audio.

No se oye ningún sonido: Prueba el botón de silencio. Revise el volumen de su computadora o smartphone. Desconecte audífono conectado a la salida de audífono.

Uno de los dos satélites no funciona: Asegure los cables de audio no están dobladas. Cambiar las bocinas izquierdo y derecho para ver si el problema persiste.

El sonido está distorsionado: Baje el volumen y / o nivel de graves. Revise el volumen de su computadora o smartphone. Trate de mover el subwoofer más cerca o más lejos de una pared o esquina para afectar el rendimiento de graves.

6. Especificación

Fuente de poder: 120 VCA 60 Hz
Potencia pico total: 100 vatios
Potencia RMS total: 50 vatios
Potencia RMS satélites: 12.5 vatios x 2
Potencia RMS subwoofer: 25 vatios x 1
Respuesta de frecuencia: 20 Hz a 20 kHz
Satélites: doble woofer de 3 pulgadas y tweeter de 1 pulgada con gabinete de madera
Subwoofer: doble subwoofer de 5 pulgadas con gabinete de madera
Dimensiones satélites: 3.94 x 10.52 x 4.93 pulgadas
Dimensiones subwoofer: 6.58 x 12.05 x 9.49 pulgadas
NO CUENTA CON MODO DE ESPERA

7. Cumplimiento de las normas

Información de la FCC Clase B

Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, de conformidad con la Parte 15 del Reglamento de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias perjudiciales en una instalación residencial. Sin embargo, no hay ninguna garantía de que no se produzcan interferencias en una instalación en particular.

Cumplimiento CE para Europa

Este equipo ha sido probado y cumple con los límites de Directiva del Consejo Europeo sobre la aproximación de la legislación de los estados miembros en materia de compatibilidad electromagnética (89/336/CEE), de acuerdo según EN55022 Clase B.

8. Garantía limitada

Arion Legacy garantiza que el producto, en el curso de su uso normal, estará libre de defectos de material y mano de obra por un periodo de un (1) año. Este período de garantía limitada comenzará en la fecha de compra que aparece en su recibo. Arion Legacy no tendrá ninguna responsabilidad por cualquier producto devuelto si Arion Legacy determina que el producto no fue comprado a distribuidores autorizados, o si el defecto a) no está presente, b) no se puede recticar razonablemente debido a daños producidos antes que Arion Legacy recibe el producto, o c) es atribuible al mal uso, instalación inadecuada, alteraciones (incluyendo el retiro de componentes o alteraciones a etiqueta de garantía). Al ser reparado por Arion Legacy, la garantía de su producto sera basada en el período restante de la garantía original o noventa (90) días a partir de la fecha de envío de un producto reparado o reemplazado, lo que sea mayor.

9. Contáctenos

Sitio web	www.arionlegacy.com
Preguntas frecuentes	support.arionlegacy.com
Atención al cliente	1-951-373-3790 (US) customerservice@arionlegacy.com
Información general	1-844-EAGLETECH (US) 1-626-956-4040 (International)



@ArionLegacy

© 2014 Arion Legacy. Todos los derechos reservados. El logotipo de Arion Legacy y otras marcas son propiedades de Eagle Tech Computers Inc y pueden estar registradas. Todas las demás marcas son propiedad de sus respectivos dueños.